

Optics Box Update

(Add a magnetic surface)

STEP 1

Pick up a piece of steel sheet metal

This does not need to be thick.

It is available in most hardware stores



STEP 2

Remove the bottom from your current box and cut the sheet metal to the same size as the current bottom. Predrill the sheet metal to align with the current screw holes in the bottom of your box.



STEP 3

Reattach the bottom to your box sandwiching the sheet metal between your current bottom and the sides.



STEP 4

Using superglue and magnetic adhesive tape strips make your mirrors magnetic. Remove the backing of the adhesive tape and then place superglue over the adhesive. Afix the superglued magnet to the bottom of the mirror. Let it dry.

